

# SUPER

## VOLVO TRUCK CATALOG



# OEM NUMBERS REFERENCE LIST

## VOLVO TRUCK

OEM NUMBER	SUPER NO	OEM NUMBER	SUPER NO	OEM NUMBER	SUPER NO
192206	50632	1652622	100373	9460932	150097
192226	50359	1652776	100285	9472705	100122
240022	10209	1662607	100217	9484486	100140
240022	10022	1695593	10244	9486424	100141
244073	10022	1696066	100091	9587262	50245
267075	50124	1699474	10344	9588112	10090
267268	50165	1926005	10209	9680125	100040
267269	100194	1926005	10022	10895522	100076
267316	50646	2400224	10209	11018690	100042
424580	50461	2440733	10022	15223720	150061
424983	100052	2670750	50124	15228950	100142
430132	50219	2672681	50165	15232390	100286
469336	150080	2672699	100355	15236342	150219
477118	100350	2672699	100194	15438963	200023
477119	150077	2673168	50646	15776248	150072
943704	100194	3092046	10049	15877921	100136
943741	10216	3121584	100168	15877921	100136
944667	150072	3121584	100194	16100786	50192
948448	100140	3192069	150220	16107658	150081
948642	100141	3192615	150219	16526220	100373
968012	100040	3410503	10031	16527764	100285
1089552	100076	3463817	50194	16960668	100084
1218389	100168	3514943	10315	20375790	100375
1218389	100194	4245809	50461	20399560	100375
1266605	50219	4693362	150080	20412286	150069
1276424	50219	4771184	100350	20412568	100360
1276425	50219	4771192	150077	20476025	50165
1521431	50165	6613348	50531	20518642	600070
1522372	150061	6797454	50465	20525916	10209
1522895	100142	6876126	50065	20525916	10022
1522896	150074	6876127	50057	20591881	150207
1523239	100286	6876131	50162	20772463	150097
1524281	150189	6876132	50161	20852864	100206
1524838	100052	6876138	10336	67709642	50648
1543896	200023	6876348	10025	67974543	50465
1546480	50629	9437047	100194	68761261	50065
1577624	150072	9443310	10315	68761279	50057
1587792	100136	9446659	150037	68761311	50162
1587792	100136	9446667	150123	68761329	50161
1610765	150081	9446675	150072	68761386	10336
				68763481	10025

# VOLVO TRUCK

ISO 16949

## ENGINE

Dimensions	Type	Material	O.E.M Number	
<b>SUPER / 50629</b>				
front crankshaft				
45x62x8	S4L RD	VMQ	1546480	
<b>SUPER / 50219</b>				
front crankshaft				
			1266605	1276424
52x68x8	S4L RD	FPM	430132	1276425
<b>SUPER / 50531</b>				
front crankshaft				
FLC				
60.33x79.62x9.52/11.11	S3L RD	FPM	6613348	
<b>SUPER / 100350</b>				
front crankshaft				
FM7;F6:F7:FL6;FL7				
76,20x101,60x11.90	S4L RD (L Special)	FPM	477118	4771184
<b>SUPER / 100360</b>				
front crankshaft				
FE;FL				
81x104x11	S4L RD (L Special)	FPM	20412568	
<b>SUPER / 100272</b>				
front crankshaft				
F10;FM7				
85,72x114,45x14,28	S3L RD	FPM		
<b>SUPER / 100052</b>				
front crankshaft				
F10;FM7				
85,73x114,33x13/9.50	S4L RD	FPM	424983	4695078
			1524838	
<b>SUPER / 100194</b>				
rear crankshaft				
			267269	9437047
80x100x10	S1L LD	FPM	2672699	1218389
			943704	3121584
<b>SUPER / 150077</b>				
rear crankshaft				
FM7;F6:F7:FL6;FL7				
F6				
127x150x13	S4L LD	FPM	477119	4771192
<b>SUPER / 150069</b>				
rear crankshaft				
FE;FL				
130x150x13	S3L LD (L Special)	VMQ	20412286	

# VOLVO TRUCK

ISO 16949

## ENGINE

Dimensions	Type	Material	O.E.M Number	
<b>SUPER / 150080 rear crankshaft F10;FM7</b>				
155x180x15	S4L LD	FPM	469336	4693362
<b>SUPER / 200023 rear crankshaft FL12;F16;FM12;FM9;FH16</b>				
180x205x15	S4L LD	FPM	1543896	15438963
<b>SUPER / 10090 water pump F12 FH12 FH16 FL10 N12</b>				
15x35x7	S3L	NBR	9588112	
<b>SUPER / 10022 injection pump FL6/FL7</b>				
			1926005	20525916
25x35x7	S3	NBR	244073	2440733
			240022	2400224
<b>SUPER / 10209 injection pump FL6/FL7</b>				
			1926005	20525916
25x35x7	S3L	NBR	244073	2440733
			240022	2400224
<b>SUPER / 50461 injection pump drive shaft</b>				
29x50x10/7	S4L LD	VMQ	424580	4245809
<b>SUPER / 50621 injection pump drive shaft</b>				
34.5x62x6	S4L LD	VMQ		
<b>SUPER / 10344 injection pump FS 7</b>				
35x47x7	S3	FPM	1699474	
<b>SUPER / 10315 air compressor shaft</b>				
			3514943	
30x47x7	S3L	FPM	9443310	

## GEARBOX

Dimensions	Type	Material	O.E.M Number	
<b>SUPER / 10336</b>				
Lever Selection Shaft				
25x32x5	S1y	NBR	6876138	68761386
<b>SUPER / 10025</b>				
Lever Selection Shaft				
25x35x7	S1L E4R9835	NBR	6876348	68763481
<b>SUPER / 10216</b>				
Lever Selection Shaft				
26x36x7/8	S3L	NBR	943741	
<b>SUPER / 50057</b>				
input gearbox outer side				
48x65x10	S1L	NBR	6876127	68761279
<b>SUPER / 50465</b>				
input gearbox				
48x65x10	S4L RD	FPM	6797454	67974543
<b>SUPER / 50065</b>				
input gearbox inner side				
48x69x10	S1 RD	FPM	6876126	68761261
<b>SUPER / 50219</b>				
Input gearbox				
			1266605	1276425
52x68x8	S4L RD	FPM	1276424	430132
<b>SUPER / 50245</b>				
Power takeoff				
55x80x10	S1	VMQ	9587262	
<b>SUPER / 50646</b>				
Gearbox				
59.90x80x8/10	S1L RD	FPM	267316	2673168
<b>SUPER / 50648</b>				
Output Gear Box				
60x74x10	S1L LD	FPM	67709642	

# VOLVO TRUCK

ISO 16949

## GEARBOX

Dimensions	Type	Material	O.E.M Number	
<b>SUPER / 50165</b>				
input gearbox				
F7;FL12;FM10;FH16				
64,9x90x10	S1L RD	FPM	267268	2672681
			1521431	20476025
<b>SUPER / 50161</b>				
output gearbox inner side				
FL6				
70x90x10	S3	NBR	6876132	68761329
<b>SUPER / 50162</b>				
output gearbox inner side				
FL6				
70x90x10	S3 LD	FPM	6876131	68761311
<b>SUPER / 100168</b>				
Output Gear Box				
FL6 FS 7				
80x100x10	S3 LD	FPM	3121584	1218389
<b>SUPER / 100355</b>				
Output Gear Box				
F7 F10 F12 FL7				
FL10 N10 N12				
80x100x10	S4L LD	FPM	2672699	
<b>SUPER / 100373</b>				
output gearbox outer side				
FH12;FM9;FM7;FM12;FH16;FL12;FM10				
90x111x6/8	S3y	NBR	1652622	16526220
<b>SUPER / 100285</b>				
output gearbox inner side				
FL12;FM10;FM7;FH16				
90x145x10	S4L LD	FPM	1652776	16527764
<b>SUPER / 100206</b>				
Output Gear Box				
FE FL				
105x125x13	S4L LD	FPM	20852864	
<b>SUPER / 100217</b>				
output gearbox				
105x130x12	S4L LD	VMQ	1662607	

# VOLVO TRUCK

ISO 16949

## REAR AXLE

Dimensions	Type	Material	O.E.M Number	
<b>SUPER / 50632</b>				
pins steering knuckle				
45x77x4/7.80	S1y	NBR	192206	
<b>SUPER / 50192</b>				
outer wheel hub				
F7 F10 F12 F13 FL7 FL10 N10 N12				
77x98,4/103x6,3/19,3	S1y	NBR	16100786	
<b>SUPER / 100076</b>				
wheel hub				
F12;F16;F10;F7;FL7;FL10 FL12;FL6;FH12;FH16;FM12;FM9;FM10				
110x140x12/19	S5L RLD Sp	FPM	1089552	10895522
<b>SUPER / 100136</b>				
wheel hub				
F7;F10;F12;N10;N12				
110x140x12/21	S3L RLD Sp	NBR	1587792	15877921
<b>SUPER / 100084</b>				
wheel hub				
F12				
120x140x13	S2	NBR	16960668	
<b>SUPER / 100091</b>				
wheel hub				
120x140x13	S3	NBR	1696066	
<b>SUPER / 150207</b>				
inner wheel hub				
FL				
120x150x15/12	S4L	FPM	20591881	
<b>SUPER / 600070</b>				
wheel hub				
125x148.3/156x8.1/9.3	CASSETTE	FPM	20518642	
<b>SUPER / 100375</b>				
wheel hub				
125x148x9.7	S4L Sp	FPM	20375790	20399560
<b>SUPER / 600071</b>				
outer wheel hub				
130x170x18/20	CASSETTE	FPM	85109330	

## REAR AXLE

Dimensions	Type	Material	O.E.M Number	
SUPER / 150061	inner wheel hub	F12;F16;F10;FL10;FL12; FM10;FH12;FM7;FH16		
140x164x20/23,5	S2L RLD KOMBI	FPM	1522372	15223720
SUPER / 150037	wheel hub	F12 N12		
148x170.2x31.50	S1 RLD	NBR	9446659	
SUPER / 150051	wheel hub	F12;F16;F10;F7;FL7 FL12;FL6;FH12;FH16;		
150x180x10	S2y	AU		
SUPER / 150189	outer wheel hub	F12 N12		
150x180x10	S1L2y Sp	NBR	1524281	
SUPER / 150074	inner wheel hub	F12 N12		
150x180x16/18	S1L2 RLD	FPM	1522896	
SUPER / 150081	inner wheel hub	F12;F16;F10;F7;FL7;FL10 FL12;FL6;FH12;FH16;		
SUPER / 150123				
168x190/188x30/32	S1L RLD	FPM	16107658	1610765
SUPER / 100009	differ. bevelgear outer side			
80x100x10	S3	NBR	9590423	959042
SUPER / 100140	output differential	FM10;FH16		
80x110,05x12	S1L LD	FPM	948448	9484486
SUPER / 100142	differential bevelgear	F10;F7;FL7;FL10 FM12;FM10;FH12;FM7;FH16		
80x130,2x12/20	S2L RD	FPM	1522895	15228950
SUPER / 100373	output differential			
90x111x6/8	S3y	NBR	16526220	1652622



# VOLVO TRUCK

ISO 16949

## REAR AXLE

Dimensions	Type	Material	O.E.M Number	
<b>SUPER / 100141</b>	<b>input differential</b>	<b>F10;FM12;FM10;FH12;FH16</b>		
90x125,25x10	S1L RD	FPM	948642	9486424
<b>SUPER / 100286</b>	<b>differential bevelgear</b>	<b>FM10;FH16</b>		
90x145x10/15	S4L RD	FPM	15232390	1523239
<b>SUPER / 150219</b>	<b>input differential</b>	<b>FH12;FM9;FM7;FM12;FH16;FL12</b>		
90x151x10/15	S4L RD	FPM	15236342	3192615
<b>SUPER / 150220</b>	<b>input differential</b>	<b>FM10;FM9;FM7;FM12</b>		
90x151x11/17	S2L RD	FPM	3192069	

## FRONT AXLE

<b>SUPER / 50096</b>	<b>pins steering knuckle</b>			
48x76x9	S1y	NBR		
<b>SUPER / 50379</b>	<b>pins steering knuckle</b>			
50x62x5	S3y	NBR		
<b>SUPER / 50092</b>	<b>pins steering knuckle</b>			
50x75x9.70	S3y	NBR		
<b>SUPER / 50359</b>	<b>pins steering knuckle</b>			
52x68x6	S1y	NBR	192226	
<b>SUPER / 100122</b>	<b>wheel hub</b>	<b>F6</b>		
85x110x13	S3L	NBR	9472705	
<b>SUPER / 600068</b>	<b>wheel hub</b>			
98x125.15/133.8x9.6	CASSETTE	FPM		

# VOLVO TRUCK

ISO 16949

## FRONT AXLE

Dimensions	Type	Material	O.E.M Number	
<b>SUPER / 100379 wheel hub</b>				
98x125x8	S1 Sp	FPM		
<b>SUPER / 100040 wheel hub</b>				
		FL6	FLC	
100x120x12	S3	NBR	968012	9680125
<b>SUPER / 100042 wheel hub</b>				
100x120x13	S2L	NBR	11018690	
<b>SUPER / 100094 wheel hub</b>				
105x130x12	S3L	NBR	1526828	1526828.7
<b>SUPER / 100076 wheel hub</b>				
		F12;F16;F10;F7;FL7;FL10 FL12;FL6;FH12;FH16;FM12;FM9;FM10		
110x140x12/19	S5L RLD Sp	FPM	1089552	10895522
<b>SUPER / 100136 wheel hub</b>				
		F7;F10;F12;N10;N12		
110x140x12/21	S3L RLD Sp	NBR	1587792	15877921
<b>SUPER / 150097 wheel hub</b>				
		F10 F12 N10 N12 946093		
125x150x13	S1L	NBR	9460932	20772463
<b>SUPER / 150072 wheel hub</b>				
		F12;F10;F7		
133,30x155,6x14	S1 RLD	NBR	9446675	944667
<b>SUPER / 50124 differential bevelgear</b>				
		FM9		
65x90x13	S1L	NBR	267075	2670750
<b>SUPER / 50485 Output Differential</b>				
		2077345		
65x90x10	S3	FPM		

